

S&A

W-2200B DUAL CHAMBER TEMPERATURE TEST SYSTEM With 250B-1 or 250C Network Analyzer

- Automated software based quartz crystal temperature test system
- Measures over 75 different parameters
- Parameter and curve fit characteristics are checked against easy to define QC limits
- Crystals of different frequencies can be tested in a single temperature run
- All data published in a *Microsoft Access*™ data base and can be exported to *Microsoft Excel*™ for custom data analysis
- Crystal part number can be used to set complete measurement parameters, QC limits, temperature test points, and data printouts
- Printouts are generated using *Crystal Reports*®



- Accommodates two dual row test wheels with extended life test head contacts
- Easily loaded S&A proprietary sockets accept HC-45, HC-49, HC-43, HC-49US, HC-18, SMD and tubular type packages
- Typically holds 1016 devices per run

SPECIFICATIONS

250B-1 Frequency Range:
250C Frequency Range:

15 KHz to 220 MHz
15 KHz to 500 MHz

Frequency Correlation:

+/- 1 ppm* at series (typical)

Crystal power:

1 nW to 1000 uW (1 MHz to 50 MHz)
1 nW to 500 uW (>50 MHz to 200 MHz)

Temperature Stability:

±0.1°

* Proprietary measurement and calibration algorithms provide correlation to industry standard crystal measurement equipment.

SAUNDERS & ASSOCIATES, INC.

2520 E. Rose Garden Lane - Phoenix, Arizona 85050 USA (602) 971-9977 FAX (602) 971-5522
E-Mail sales@saunders-assoc.com - World Wide Web <http://www.saunders-assoc.com>

